


ACID-BASE TITRATIONS

CONCEPT MAP

Class
XI

Titration has wide applications in food industry, medical field as well as in automotive industry. In medical, it is used to determine proper concentration of anaesthetics and to measure glucose level in the blood. In automotive, it is used during production of biodiesel fuel.



- **Titration** is the measurement of the volume of a solution of one reactant that is required to react completely with a measured amount of another reactant.
- The solution which is to be titrated is called *titrate*.
- The solution with which the titration is to be done is called the *titrant*.
- The substance usually added into the solution taken in the titration flask to detect the equivalence point is called an *indicator*. The *equivalence point* is the ideal point for the completion of titration, *i.e.*, it is the exact point in a titration when moles of one titrant becomes equal to the moles of the substance being titrated.
- The *end point* is the point at which the indicator just changes its colour. End point indicates that equivalence point has been reached.
- The point at which there is a sudden change in pH when a very small amount of the titrant is added to the titrate is called *point of inflection*.
- The curve between pH values of the solution and the volume of titrant added as the titration proceeds is called a *titration curve*.
- The determination of concentration of bases by titration with a standard acid is called *acidimetry*.
- The determination of concentration of acids by titration with a standard base is called *alkalimetry*.

Types of Indicators

- **Self indicator** : A substance is said to be self indicator if it itself acts as an indicator in titration *e.g.*, potassium permanganate (KMnO_4) and oxalic acid (COOH)₂.
- **External indicator** : In some redox titrations, the end point is detected with the help of a substance which is not added to the solution being titrated but used outside the titrating system, *e.g.*, potassium ferricyanide.
- **Internal indicator** : The substance or reagents which are added to the solution in the conical flask or beaker during the titration to find out the end point, *e.g.*, phenolphthalein, methyl orange, starch solution, etc.